

BYD BATTERY-BOX PREMIUM HVS&HVM COMPATIBLE INVERTER LIST - V2.8



[DE] BYD Battery-Box Premium HVS / HVM kompatible Wechselrichterliste

[ES] Lista de Inversores Compatibles con Battery-Box Premium HVS/HVM

[IT] Lista di Configurazione Minima e degli Inverter Compatibili con BYD Battery-Box Premium HVS/HVM

Inverter [DE] Wechselrichter [ES] Inversores [IT] Inverter	Module Quantity [DE] Modulanzahl [ES] Cantidad de módulo [IT] Quantità moduli	Minimum Firmware Version													
		Single Tower [DE] Einzelturm / [ES] torre única / [IT] torre singola				Parallel Connection [DE] Parallelschaltung / [ES] conexión paralela / [IT] connessione parallela									
		HVS		HVM		Inverter		Battery-Box		Inverter		Battery-Box			
						BMU		BMS		Inverter		BMU		BMS	
Fronius	Symo Hybrid	-	3-8	1.16.6-1	3.13	3.19	1.16.7-1	3.14	3.20						
	Symo GEN24 Plus	2-4	4-8	1.9.7-0	3.13	3.19	1.10.5-0	3.14	3.20						
	Primo GEN24 Plus	2-3	4-7	1.11.6-0	3.15	3.21	same as single tower								
	Note: Parallel connection is not possible for Fronius inverters in the configuration: 3 x HVM 22.1 [DE] Parallelschaltung ist mit Fronius Wechselrichtern nicht möglich für die Konfiguration: 3 x HVM 22.1 [ES] La conexión en paralelo no es posible para los inversores Fronius en la configuración: 3 x HVM 22.1 [IT] Il collegamento in parallelo non è possibile per gli inverter Fronius nella configurazione: 3 x HVM 22.1														
GoodWe	ET/BT	2-5	4-8	ARM 11	3.13	3.19	same as single tower								
	EH/BH	2-4	3-8												
Viessmann	A3	2-5	4-8	ARM 11	3.13	3.19	same as single tower								
KOSTAL	Plenticore Plus 3.0	2-5	4	01.42	3.13	3.19	same as single tower								
	Plenticore Plus 4.2/5.5/7.0/8.5/10.0	2-5	4-8												
	Plenticore BI 5.5-13/ 5.5-26	2-5	5-8												
	Plenticore BI 10.0-26	3-5	5-8	PU-APP 3.7.0, KSEM 1.2.0.	3.13	3.19									
	Piko MP Plus 1.5-1/2.0-1/ 2.5-1	2-3	3-4												
	Piko MP Plus 3.0-1, 3.0-2, 3.5-1, 3.5-2, 4.6-2, 5.0-2	2-5	3-8	2.32	3.16	3.24									
SMA	Sunny Boy Storage 2.5	2-4	-	3.11.06R	3.15	3.21	same as single tower								
	Sunny Boy Storage 3.7/5.0/6.0	2-4	3-8	For HVS: 3.11.03R For HVM: 3.11.10R	3.13	3.19	-								
	STP 5.0-10.0 SE	2-5	4-8	3.00.02.R	3.16	3.24	same as single tower								
	Note: For SBS 3.7 / 5.0 / 6.0 no parallel connection - check inverter manual how to connect up to three batteries [DE] Für SBS 3.7 / 5.0 / 6.0 keine Parallelschaltung - siehe Wechselrichterhandbuch, wie man bis zu drei Batterien anschließt [ES] Para SBS 3.7 / 5.0 / 6.0 sin conexión en paralelo disponible: consulte el manual del inversor sobre cómo conectar hasta tres baterías [IT] Per SBS 3.7 / 5.0 / 6.0 nessuna connessione parallela è disponibile - controllare il manuale dell'inverter come collegare fino a tre batterie														
Sungrow	SH5.0/6.0/8.0/10RT	2-5	4-8	ARM, V11_V01_B MDSP, V11_V01_B	3.13	3.19	same as single tower								
	SH3.0/3.6/4.0/5.0/6.0RS	2-4	3-8	ARM, 01011.02.16 MDSP, 03011.02.15	3.16	3.24									
KACO	Blueplanet hybrid 6.0 - 10.0 TL3	2-4	3-8	5.8.6.3.7	3.13	3.19	same as single tower								
Ingeteam	ISS 1Play 3TL M / 6TL M	2-4	3-8	ABH1007_F	3.15	3.22	same as single tower								
	Note: Only compatible with BCU produced since 1st October, 2020. [DE] Nur kompatibel mit BCU, die seit dem 1. Oktober 2020 produziert wurden [ES] Solo compatible con BCU fabricados desde el 1 de octubre de 2020. [IT] Compatibile solo con BCU prodotte dal 1 ottobre 2020.														
Solis	RHI-3P(5-10)K-HVES-5G	2-5	4-8	V090037	3.16	3.22	V090037	3.16	3.24						
GE	GEH5.0/8.6/10-1U-10	2-5	3-8	000019	3.17	3.24	same as single tower								



BYD Company Limited
www.bydbatterybox.com
batteryboxgrp@byd.com
bboxservice@byd.com

Battery-Box EU Service Partner
EFT-Systems GmbH
www.eft-systems.de
service@eft-systems.de

Battery-Box AU Service Partner
Alps Power Pty Ltd
www.alppower.com.au
service@alppower.com.au

Battery-Box South Africa Service Partner V2.8
AFRIPLUS ENERGY GROUP (PTY) LTD
2022-7-5
support@afriplusenergy.co.za



Note:

- Always install the latest firmware on the Battery-Box!
- Requirements for Parallel Connection: Maximum three battery systems could be connected in parallel; HVS system CANNOT be connected in parallel with HVM system; Every tower connected in parallel requires the same module quantity;

[DE] Bemerkung:

- Installieren Sie immer die neueste Firmware auf der Battery-Box!
- Anforderungen an Parallelschaltung: Es dürfen maximal drei Batteriesysteme parallel geschaltet werden; Ein HVS-System kann NICHT mit einem HVM-System kombiniert werden; Jeder parallel geschaltete Turm benötigt die gleiche Modulanzahl

[ES] Nota:

- ¡Instale siempre el firmware más reciente en la Battery-Box!
- Requisitos para la conexión en paralelo: se pueden conectar en paralelo un máximo de tres sistemas de baterías; El sistema HVS NO PUEDE conectarse en paralelo con el sistema HVM; Cada torre conectada en paralelo requiere la misma cantidad de módulos por torre;

[IT] Nota:

- Installare sempre l'ultimo firmware sul Battery-Box!
- Requisiti per il collegamento in parallelo: è possibile collegare in parallelo un massimo di tre sistemi di batterie; Il sistema HVS NON può essere collegato in parallelo al sistema HVM; Ogni torre collegata in parallelo richiede la stessa quantità di moduli per torri;

The information in this document is subject to change without notice. Please take the latest version of this document at our websites into account.

[DE] Die Informationen in diesem Dokument können ohne vorherige Ankündigung geändert werden. Bitte berücksichtigen Sie die neueste Version dieses Dokuments auf unseren Websites.

[ES] La información de este documento está sujeta a cambios sin previo aviso. Tenga en cuenta la última versión de este documento en nuestros sitios web.

[IT] Le informazioni contenute in questo documento sono soggette a modifiche senza preavviso. Si prega di prendere in considerazione l'ultima versione di questo documento sui nostri siti web.

