



1.Structure Description




- 1						
١	1	Body of the connector	2	(5)	Claw	2
١	2	Metal terminal	2	6	Back cover	2
١	3	Support sleeve	2	7	Heat-shrinkable sleeve	2
١	4	Sealing gasket	2			

2. Put the heat-shrinkable sleeve, back cover, claw and sealing gasket on the cable in sequence.



3. Strip the cable. Put the support sleeve on the cable, and plug the stripped cable core into the metal terminal.





4. Clamp the terminal with a hydraulic clamp or a clamping machine. (Pay attention that the right size dies should be chosen.)



Qualified clamped cable data:


Crimp width(mm)	Crimp height(mm)	Pull-out force (N)	
(15.0)	12.2~ 12.5	≧3700N	






8. Cover the sealing gasket with the claw.


9. Get the back cover close to the body, and tighten them.



10. Get the heat shrinkable sleeve on the step of the back cover. Blow hot air, and make them fit well.

11. Remove the plastic cover before plugging it into the battery system.





Contact

Australia: Alps Power Pty Ltd USA: BYD US Service service@alpspower.com.au Telephone:+61 2 8005 6688

Europe: EFT-Systems GmbH service@eft-systems.de +49 9352 8523999

Telephone: +44(0)2037695998(UK) +34 91 060 22 67(ES) +39 0287 368364(IT)

bboxusservice@byd.com Telephone:+1(833)338-8721

South Africa: AFRIPLUS ENERGY GROUP (PTY) Support@afriplusenergy.co.za +86 755 89888888-47175 Telephone:+27 21 140 3594

LATAM: BYD LATAM Service bboxservLATgrp@byd.com

BYD Global Service: bboxservice@byd.com Telephone:

Service policy is subject to BYD's product warranty.

Economic Operator In Europe: BYD Smart Device Hungary kft. Brand: BYD

Address: H-2071 paty, Szeng Jozsef ut 4.